



P. O. Box 878
Trenton, NJ 08605
Fax: 609-396-7985
info@homerubber.com
www.homerubber.com

9/20/2004

CARE AND STORAGE OF TAN PURE GUM TUBING

Tan Pure Gum Tubing is made from natural rubber (NR).

NR is susceptible to discoloration and cracking from exposure to sunlight and ozone. NR is extremely susceptible to cracking or "dry rot" when exposed to ozone or sunlight and ozone together.

Light shining through an open window, and even fluorescent light exposure, can discolor tubing in a short period of time.

TO PREVENT DISCOLORATION AND CRACKING; STORE TAN PURE GUM TUBING IN A COOL DARK LOCATION, PROTECTED FROM LIGHT, ESPECIALLY DIRECT SUNLIGHT

Some options for safe storage are:

- Keep the tubing in the original shipping carton.
- Cover the tubing with a protective blanket.
- Store tubing on a shelf away from windows and artificial light sources.
- Protect from fluorescent lighting and sources of ozone like electric motors.

For information about Home Rubber's sun and ozone resistant tubing products, see our 1200P data sheet.

DON'T FORGET TO CALL HOME FOR TUBING PRODUCTS

800-257-9441